



FLASH INDICATION

	1 FLASH PER SECOND
	12 FLASHES PER SECOND

ALARM STATUS FAULT

		BLOCKED
		LOW VOLTAGE
		ELECTRICAL ERROR

DEFAULT SETTING

	OPERATING PANEL	CONTROL MODE	
0		PROPORTIONAL PRESSURE AUTO ADAPT	
1		CONSTANT PRESSURE AUTO ADAPT	
2		PROPORTIONAL PRESSURE 1	
3		PROPORTIONAL PRESSURE 2	
4		PROPORTIONAL PRESSURE 3 - MAX	
5		CONSTANT PRESSURE 1	
6		CONSTANT PRESSURE 2	
7		CONSTANT PRESSURE 3 - MAX	
8		CONSTANT CURVE 1	
9		CONSTANT CURVE 2	
10		CONSTANT CURVE 3 - MAX	
11		PWM PROFILE C - SIGNAL OFF	
		PWM PROFILE C - SIGNAL ON	
12		PWM PROFILE A 1 - SIGNAL OFF	
		PWM PROFILE A 1 - PWM SIGNAL ON	
13		PWM PROFILE A 2 - SIGNAL OFF	
		PWM PROFILE A 2 - PWM SIGNAL ON	
14		PWM PROFILE A 3 - SIGNAL OFF	
		PWM PROFILE A 3 - PWM SIGNAL ON	